

# PLB and AIS Beacon Fitting Instructions













### **Included Beacons:**

### Personal Locator Beacons

- Ocean Signal RescueME PLB1
- ACR ResQLink

### **AIS Beacons**


- Ocean Signal MOB1
- Ocean Signal M100
- ACR AIS Link
- SIMY My-AIS

## Ocean Signal MOB1 Fitting Instructions




### **Ocean Signal MOB1**


Always refer to Ocean Signal MOB1 documentation alongside these instructions. Ensure unit is compatible with chosen life jacket.




#### Fitting Instructions

Open life jacket and ensure everything is in working order. Locate attachment point.





Ensure an audible "CLICK" is heard from each clip on the Mounting Backet. The unit is now fixed and secure.



Activation Tape Threaded through hole in bladder.

# Ocean Signal M100 Fitting Instructions




### Ocean Signal M100


Always refer to Ocean Signal M100 documentation alongside these instructions. Ensure unit is compatible with chosen life jacket.







Open life jacket and ensure everything is in working order. Locate attachment point.





Position M100 unit as shown. Ensure an audible "CLICK" is heard from each clip on the Mounting Backet. The unit is now fixed and secure.









Please ensure Activation Tape does not go through hole in bladder

## ACR AIS Link Fitting Instructions



### **ACR AIS Link**


Always refer to ACR AIS Link documentation alongside these instructions. Ensure unit is compatible with chosen life jacket.







### Fitting Instructions

Open life jacket and ensure everything is in working order. Locate attachment point.





Position AISLink Unit as shown. Ensure an audible "CLICK" is heard from each clip on the Installation Backet. The unit is now fixed and secure.



## SIMY My-AIS Fitting Instructions



### **SIMY My-AIS**

Always refer to SIMY My-AIS documentation alongside these instructions. Ensure unit is compatible with chosen life jacket.







Strap Clip


### Fitting Instructions

Open life jacket and ensure everything is in working order. Locate attachment point.





Position MyAIS Unit as shown. Ensure an audible "CLICK" is heard from each clip on the Strap Clip. The unit is now fixed and secure.






### Ocean Signal rescueME PLB1

Always refer to Ocean Signal rescueME PLB1 documentation alongside these instructions. Ensure unit is compatible with chosen life jacket

### Required components






1. Ocean Signal rescueMEPLB1 Unit

2. Mounting Bracket


### Fitting Instructions


Open life jacket and ensure everything is in working order. Locate attachment point.



(1)Position Mounting Bracket as shown.







- Ensure an audible "CLICK" is heard from each clip on the
- Retainer Clip.

  The unit is now fixed and secure.
  Re-pack life jacket according to packing instructions.


### **ACR ResQLink**



### ACR ResQLink

Always refer to ACR ResQLink documentation alongside these instructions. Ensure unit is compatible with chosen life jacket.

#### Required components







1. ACRResQLink Unit

2. InstallationBracket

### Fitting Instructions

Open life jacket and ensure everything is in working order. Locate attachment point.







- Ensure an audible "CLICK" is heard from each clip on the Installation Bracket

  The unit is now fixed and secure.

  Re-pack life jacket according to

  - packing instructions.